IP PHONE 485G QUICK REFERENCE

Powering connections

PHONE OPERATION

Place Calls

Use the speakerphone or a headset

Use the Directory

Make a conference call

Make a call from History

Use the Intercom (through Directory)

Answer Calls

Answer a call

Send a call to voicemail

Divert an incoming call

Adjust volume of handset, headset, or speakerphone when off hook; adjust ringer volume when on hook

Answer call waiting (incoming call)

Pick up a call for another extension

Interact with Calls

Mute a call

Place a call on hold

Take a call off hold

Transfer a call

Merge calls into a conference call

Park a call on another extension

Unpark a call



















Press green blinking call appearance button or













VOICEMAIL

Check visual voicemail

Log in to voicemail main menu

Log in from another extension



EXTENSION ASSIGNMENT

Using Phone Interface

Assign ext. to Available or Assian Anonymous phone



Unassign extension


Assign your ext. to an assigned phone



Using Voicemail System

Change ext. assignment

Unassign extension



CUSTOMIZE YOUR PHONE

Select a ringtone

Change availability



Change avail. state and call forwarding

state









+Ringtone +



Change wallpaper







Change time zone





Time zone

+ Unassign user + Unassign + Unassign

Log in or out of workgroup




4 O F Agent state



TROUBLESHOOTING

View phone information Reboot your phone










Note: For details about using the phone, see the IP Phone 485g User Guide.

IP PHONE 485G QUICK REFERENCE





Note: You can connect supported headsets to the IP Phone 485g via the headset jack on the back of the phone.

GUIDE TO LEDS

Your 485q IP phone provides color cues to help you determine call appearance status:

- Steady Green: Phone is in use (dialing or off hook)
- Blinking Green: Incoming call
- Blinking Orange: On hold or call parked
- Steady Orange: Extension's availability state set to Do Not Disturb or phone in a No Service state. For BCA, the monitored extension is in use by another party but you can join the call
- Steady Red: Monitored extension is in use by other party (applies to BCA and Extension Monitor)

Presence Icons

In Directory and History (details view), the following icons indicate a person's current phone status:



Available



Custom availability state



On hold or has a call parked



Do not disturb



On a Call

GUIDE TO STATUS ICONS

Main Display



Unheard Voice Messages



Missed Calls



Logged in to Workgroup



ogged in to Workgroup, in Wrap-Up



Logged out of Workgroup



Available



In a Meeting or Do not Disturb



Out of Office



Vacation



Custom

Call Appearance



Idle, On Hook



Off Hook, Dialing



Inactive / Do Not Disturb



Incoming Call



Connected Call



Connected Conference Call



On Hold Locally



On Hold Remotely



Speed Dial Extension



Speed Dial Extension with DND



Call is being recorded



Whisper mute is active

Monitored Extension



Monitored extension



Monitored extension, DND



Unheard Messages



Unheard Messages and DND



Connected call and incoming call



On a Call



On a Conference Call



Monitored extension in a connected call and call answered locally



Monitored extension on hold and call answered locally



Monitored extension in a connected call with a call on hold

Visual Voicemail



Urgent





Message with return receipt



Private message



📆 🐧 Broadcast message



Broadcast message with return receipt requested



Private broadcast message



Private broadcast message with return receipt requested



Private message with return receipt requested